

Item	What to do	How often	Date Last Done	Date to Do Next
Engine Belts (all)	replace	5 Years		
			Int/Ext	
Engine Hoses (all)	replace	5 Years		
			Int/Ext	
Tires	replace	5 Years		
			Int/Ext	
Awning	Wash with Soap & Water	Annual		
			Int/Ext	
CO Detector	Vacuum Openings	Annual		
			Int/Ext	
CO Detector	Check Battery	Annual		
			Int/Ext	
Coach Entry Door Hinges	Lubricate with Medium Weight Motor Oil	Annual		
			Int/Ext	
Coach Entry Door Locks	NO OIL-Lubricate with Tri-Flow	Annual		
			Int/Ext	
Exterior	Wax Coach, Double Coat the Stripes	Annual		
			Int/Ext	
Main Door Latch Hardware	Lubricate With Grease	Annual		
			Int/Ext	
Satellite Antenna Display	replace 9 volt battery in display	Annual		
			Int/Ext	
Smoke Alarm	Replace Battery	Annual		
			Int/Ext	
Smoke Alarm	Vacuum all Openings, check Battery	Annual		
			Int/Ext	
TV Antenna	Remove Black Plastic Plug at Base & Lubricate with Machine	Annual		
			Int/Ext	

Item	What to do	How often	Date Last Done	Date to Do Next
Water Pump	Inspect & Clean the Debris Filter	Annual	Int/Ext	
Wheel Skirts	Grease Bolt Threads	Annual	Int/Ext	
Awning	Closed & Locked	Departure	Int/Ext	Exterior
Black & Grey Hoses	Disconnected & Stored	Departure	Int/Ext	Exterior
Cable & Phone Lines	Disconnected & Stored	Departure	Int/Ext	Exterior
Engine Oil & Water	Check	Departure	Int/Ext	Exterior
Generator	Check Oil Level & Air Filter	Departure	Int/Ext	Exterior
Kwikiee Step	Retracted	Departure	Int/Ext	Exterior
Levellers	Stored	Departure	Int/Ext	Exterior
Outside Compartments, All	Locked	Departure	Int/Ext	Exterior
Outside & Running Lights	Check	Departure	Int/Ext	Exterior
Patio Mat	Stored	Departure	Int/Ext	Exterior
Power Cord	Disconnected & Stored	Departure	Int/Ext	Exterior
Propane	Off, or Turned on for Fridge	Departure	Int/Ext	Exterior

Item	What to do	How often	Date Last Done	Date to Do Next
Tires	Check Tread and Tire Pressure	Departure	Int/Ext	Exterior
TV Antenna	Check, It Should NEVER Rest on the Roof	Departure	Int/Ext	Exterior
Water & Hoses	Disconnected & Stored	Departure	Int/Ext	Exterior
Water Pressure Regulator	Disconnected & Stored	Departure	Int/Ext	Exterior
Water Pump	Off	Departure	Int/Ext	Exterior
Air Conditioner	Off	Departure	Int/Ext	Interior
Antenna Booster	Off	Departure	Int/Ext	Interior
Black & Grey Water	Dumped	Departure	Int/Ext	Interior
Cabinets	Closed	Departure	Int/Ext	Interior
Dome Lights	Off	Departure	Int/Ext	Interior
Entry Door	Locked	Departure	Int/Ext	Interior
Fantastic Fans	Off	Departure	Int/Ext	Interior
Fresh Water	Down to Half a Tank	Departure	Int/Ext	Interior
Furnace	Off	Departure	Int/Ext	Interior

Item	What to do	How often	Date Last Done	Date to Do Next
GPS	Set Route	Departure	Int/Ext	Interior
Inverter	Off	Departure	Int/Ext	Interior
Refrigerator	Switch to Gas or Turn Off	Departure	Int/Ext	Interior
Refrigerator & Freezer	Make Sure It Is Locked	Departure	Int/Ext	Interior
Satellite Dish	Down	Departure	Int/Ext	Interior
Screen Door	Locked	Departure	Int/Ext	Interior
Shower & Bathroom	All Loose items Stored	Departure	Int/Ext	Interior
Stove & Oven	Off	Departure	Int/Ext	Interior
Switch for Vid Components-Ent	Make Sure It's Off	Departure	Int/Ext	Interior
Toilet	Close Lid	Departure	Int/Ext	Interior
TV & Amp Switch for TV	Make Sure It's Off	Departure	Int/Ext	Interior
TV Antenna	Down	Departure	Int/Ext	Interior
TV & Remote	Off & Stowed	Departure	Int/Ext	Interior
Vents and Hatches	Closed	Departure	Int/Ext	Interior

Item	What to do	How often	Date Last Done	Date to Do Next
Water Heater	Off	Departure	Int/Ext	Interior
Windows	Closed	Departure	Int/Ext	Interior
Generator	Check Oil every 4 hours during 1st 20 hours of operation	Hourly-1st 20 Hours	Int/Ext	
Generator	Change Oil After the First 20 Hours of Use	Hourly-1st 20 Hours	Int/Ext	
Generator	Change Plugs, Air Filter & Oil	Hourly-1st 50 hours	Int/Ext	
Generator	Change Oil & Air Filter or every 20 hours if Dusty Conditions	Hourly-Every 150 Hours	Int/Ext	
Generator	Check oil	Hourly-Every 20 Hours	Int/Ext	
Generator	Change Spark Plugs	Hourly-Every 450 Hours	Int/Ext	
Front End Alignment	Align	Miles-1st 1,000 Miles?	Int/Ext	
Fuel Filter	Change	Miles-1st @ 1500	Int/Ext	
Motor Oil	Change	Miles-1st @ 1500	Int/Ext	
Motor Oil	Change	Miles-2nd @ 3000	Int/Ext	
Motor Oil	Change	Miles-every 3,000	Int/Ext	
Fuel Filter	Change	Miles-every 6,000	Int/Ext	

Item	What to do	How often	Date Last Done	Date to Do Next
Air Conditioner	Operate for 30 minutes	Monthly		Int/Ext
Generator	Check Oil & Run for a minimum of TWO Hours	Monthly		Int/Ext
House Batteries	Check Water Levels, Clean Tray if Necessary	Monthly		Int/Ext
Wheels	Tighten Lug Nuts	Monthly		Int/Ext
Windows	Remove Any Dirt from The Window Tracks	Monthly		Int/Ext
Air Conditioner	Remove & Wash Foam Filters	Semi-Annual		Int/Ext
Battery & Compartment Door	Lubricate with Petroleum Jelly	Semi-Annual		Int/Ext
Battery Drawer Slides	Grease	Semi-Annual		Int/Ext
Black Water Vent	Make Sure the Vent is Clear	Semi-Annual		Int/Ext
Entry Door Guide Bolts	<i>Check Adjustment & Tightness, if loose, remove & apply lock-tite, reinst all so no drag</i>	Semi-Annual		Int/Ext
Fantastic Fans (2)	Clean Vent Screens	Semi-Annual		Int/Ext
Fire Extinguisher	Check & Replace if not Fully Charges	Semi-Annual		Int/Ext
Gr Water Drain Metal Shaft	Clean & Lubricate with Petroleum Jelly	Semi-Annual		Int/Ext
Gr Water Drain Valve Backside	Clean & Lubricate with Petroleum Jelly	Semi-Annual		Int/Ext

Item	What to do	How often	Date Last Done	Date to Do Next
Grey Water Drain Valve Face,	Clean & Lubricate with Petroleum Jelly	Semi-Annual	Int/Ext	
Headlights	Adjust	Semi-Annual	Int/Ext	
House Battery Door Latches	Lubricate with WD-40	Semi-Annual	Int/Ext	
Kwikkee Steps (see Guide)	Lubricate with Lithium Grease- NO Penetrating Oils	Semi-Annual	Int/Ext	
Refrigerator	Check that the Burner Tube is Clean, Check for Spider Webs	Semi-Annual	Int/Ext	
Roof Sealants	Inspect & Repair as Necessary	Semi-Annual	Int/Ext	
Toilet Ball Valve	De-Lime with Vinegar, Lubricate With Pledge	Semi-Annual	Int/Ext	
Water Heater L Shaped Gas Tube	Clean & Check for Spider Webs	Semi-Annual	Int/Ext	